

Snapport™

Add an outlet to any vessel from the outside!



1. Drill a 1-1/8" hole into the vessel.



2. Insert Snapport™ spigot.



3. Place retainer ring on adjustment tool.



4. Push tool and ring into Snapport™ until it "SNAPS" in.



5. Tighten Snapport™ by inserting the opposite end of the tool, then turning it clockwise.



3. Once installed, Snapport™ can accept solvent weld fittings, valves, or pipe.