

PressFast® Copper Press Tool Kit



Tool Head

Tool Jaws
1/2", 3/4", 1"

How to install/remove the tool jaws:



1. Squeeze the bottom of the head to open to jaw area.



2. Slide the jaw into the head until it clicks into place on the magnet. Do likewise with the other side.



3. To remove, pull out the pin on the side of the jaw head and push the jaw out of the tool.

How to install the tool head:



1. Turn the top lever up.



2. Pull lever out from tool.



3. Place tool head into slot and slide down as far as it will go into the tool handles.



4. Push lever in and turn down toward the bottom of the handles.

PressFast® Copper Press Tool Kit

How to use:



1. Open the jaws by squeezing the bottom of the tool head.



2. Place the jaws around the end of the fitting. Release jaws to close.



3. Turn the hydraulic knob on the handle to the "ON" position.



4. Press handles together 12-15 times until a click is heard. The moveable handle needs to be above the stationary handle for use. The tool head swivels for easy installation.



5. Turn the hydraulic knob on the handle to the "OFF" position.



6. Open the jaws by squeezing the bottom of the tool head to remove the tool from the fitting.