


# Universal Self-Piercing Saddle Valve

The Universal Self-Piercing Saddle Valve is incredibly easy to install and versatile for copper or CPVC pipe. The self-piercing tap comes with a hinged saddle for easy installation. You won't even have to turn off the water supply to install the valve.



## FEATURES:

- Self-piercing tap with hinged saddle for easy use.
- 3/4 in. GHT quarter-turn outlet.
- Use with 1/2 in. or 3/4 in. copper (type M) or CPVC pipe.
- Tap supply line without turning off water supply.
- Lead free chrome-plated brass construction.
- NBR rubber gaskets to prevent leaks.

## INSTALLATION INSTRUCTIONS:

1. Find an easily accessible location on the cold water line near the appliance where the valve will be installed.
2. Clean the pipe where the valve will be installed.
3. Be sure valve is closed before installing it onto the water line. Valve handle is in line with valve when valve is closed (as seen in photo).
4. Remove the side screw from the valve. Place the valve around the pipe. Replace the side screw and tighten valve around the pipe. Do not over tighten.
5. Turn the valve clockwise to pierce the pipe. Attach appliance connector to the valve. Check for leaks.